

ASP

Builder Gel Nail Extension



WATCH VIDEO

STEP BY STEP TUTORIAL

Create effortless, salon quality nails with the ASP Reusable Dual Nail Forms Kit, custom shapes, less filing, and flawless results every time.

PRODUCTS YOU WILL NEED

180-grit nail file, 150-grit buffer, cuticle pusher or ASP Ultra Birchwood Manicure Stick, ASP 2-in-1 Dehydrator & Cleansing Wipe, ASP Bonder or Primer, ASP Base Coat, **ASP Builder Gel**, Stiletto **Reusable Dual Nail Forms Kit**, soft dust brush, ASP No Wipe Top Coat, Milk & Honey Roll-On Cuticle & Body Oil, and a Lumina curing lamp.

Product Spotlight

ASP Reusable Dual Nail Forms Kit is your go-to system for fast, precise nail extensions with customizable shapes and a perfect finish.




NAIL PREP



1

Use a 180-grit file to shape the natural nails as desired.



2

Gently push back cuticles using a cuticle pusher or an ASP Ultra Birchwood Manicure Stick.



ASP



@aspnail



ASPnail



@ASPnails



@aspnail_

ASP BUILDER GEL NAIL EXTENSION



3 Lightly buff the nail surface with a 180-grit file or 150-grit buffer to remove shine.



4 Clean nails using ASP 2-in-1 Dehydrator & Cleansing Wipe until the nail appears dull and chalky.



5 Apply ASP Bonder or Primer to the natural nail.

REUSABLE DUAL NAIL FORM APPLICATION



1 Use the Stiletto Reusable Dual Nail Forms.



2 Select correct Reusable Dual Nail Form size. Ensure sidewalls fit edge to edge.

PRO TIP


It should cover the natural nail completely from left sidewall to right sidewall.



3 Apply a thin coat of ASP Base Coat and cure for 30 seconds.



4 Apply a thin layer of ASP Builder Gel to the natural nail, avoiding skin. Flash cure for 10 seconds.



5 Apply Builder Gel inside the well of the Reusable Dual Nail Form, creating desired length and structure.

ASP BUILDER GEL NAIL EXTENSION



- 6** Place form at a 45-degree angle and gently press down to remove air bubbles.



- 7** Flash cure for 10 seconds while holding the form in place. Repeat on all nails, then cure full hand for 60 seconds.



- 8** Remove the Reuseable Dual Nail Form by gently squeezing sides and twisting.



- 9** Refine the perimeter of the nail with a 180-grit file.



- 10** Smooth the surface of the nail, if needed and remove dust with a soft brush.



- 11** Apply ASP No Wipe Top Coat and ensure to cap the free edge. Cure for 60 seconds.



- 12** Finish the look with Milk & Honey Roll-On Cuticle & Body Oil by massaging it into the cuticles and surrounding skin.



- 13** Final Look

ASP BUILDER GEL NAIL EXTENSION



REMOVAL OF BUILDER GEL

1 File off gel top coat with a 180-grit file.

2 Apply cuticle oil to protect skin, such as ASP Milk & Honey Roll-On Cuticle & Body Oil.

3 Wrap nails with acetone.

4 Soak 15–20 minutes.

PRO TIP

Wrap hands in a warm towel to speed removal.

5 Remove wraps & gently push off softened product with a birchwood stick.

6 File remaining product if needed & buff to smooth nail surface.

7 Clean & hydrate nails with Milk & Honey Roll-On Cuticle & Body Oil.

8 Finish with ASP Nail Treatment or Top Coat.